

# OWNER'S MANUAL FX1000B Style Phone



## OPERATION AND MAINTENANCE

### ASSEMBLY INSTRUCTIONS

#### **Note:**


If you have high speed internet without a central splitter you may need an ADSL filter between the phone and the wall jack point. The typical symptom of a jack point requiring a filter is loud static and hissing sounds in the earpiece (check other telephones devices on this line, if they have a filter installed then this jack point will need one as well)

As you add more telephones or telephone devices to your wiring, ringing can sometimes become intermittent on some or all connected devices as the maximum loading is reached.

1. Remove the leads from the packaging. The handset curly cord and the cable that connects your phone to the wall socket must be connected correctly or the telephone will not operate. (SEE PICTURES BELOW)
2. Plug the curly cord into the handset socket.
3. Plug the other end of the curly cord into the socket located on the left hand side of the telephone.
4. Plug the telephone line cable to the socket located on the top edge of the telephone

### NOTE CORRECT CORD POSITIONS

#### DESKTOP USE (factory default as shipped)




Handset wall clip with smooth side uppermost

#### FOR DESKTOP USE

Wall mount bracket removed

## **WALL MOUNTING**

Clip the bracket supplied to the rear of your telephone to keep the phone on the correct angle when wall mounting. **IMPORTANT.** Locate the handset locking tab on the main body of the telephone just below the hook switch. Slide up this tab and reinstall it with the tongue protruding. This tongue hooks into the handset when wall mounting to prevent the handset falling.



### **DIALLING**

To make a call, lift the handset, listen for the dial tone and press the appropriate buttons for the number you require.

### **REDIAL**

To redial the last number called, pick up the handset (or depress the handset switch briefly). Then press the "Redial" button. The phone will automatically redial the last number dialled.

### **RECALL / FLASH**

This button provides a timed hookflash for use with special Telecom services such as "Call Waiting" or with PABX

### **MUTE**

Holding the "Mute" button down will prevent the caller at the other end hearing your conversation until the button is released.

### **RINGER VOLUME HI/LOW**

Use this switch to select either a high or low volume ringer sound.

### **RINGER ON/OFF**

Use this switch to switch ringer on or off. The ring indicator will still flash to show incoming calls.

### **FAULTS**

If your Custom telephone is failing to make call or ring :

Make sure the leads are connected correctly.

Make sure that all handsets on all telephones are properly "hung up"

Try a different telephone in the same wall socket

Try the same telephone in other wall sockets.

Try any other combination including having only one telephone connected at any one time.

Check that the ringer switch is in the desired position.

By now you should have isolated the problem to a specific telephone or determine if there is a line fault. In the event of a line fault, contact your local Telecom office. Should the telephone be at fault, arrange for its repair. Please do not reconnect it to the Telecom network.

### **SERVICE**

Your Custom telephone is fully guaranteed for twelve months from the date of purchase. Please keep the original packing material and proof of purchase. In the event of a fault please return the telephone to the store where you purchased it, with your proof of purchase. This guarantee does not cover damage resulting from misuse or negligence or damage resulting from excessive voltage experienced from the Telecom network. The unauthorized disassembly of this telephone will negate this guarantee.

### **HOW TO KEEP THE TELEPHONE IN GOOD CONDITION :**

Do not place your telephone in direct sunlight.

Do not expose it to hot or humid conditions.

Do not spray with aerosol polishes.

To clean, wipe with a damp cloth.

### **NOTES FOR THE USE OF THIS DEVICE IN NEW ZEALAND**

the grant of a Telepermit for a device in no way indicated Telecom acceptance of responsibility for the correct cooperation of that device under all operating conditions.

This equipment shall not be used in any manner which could constitute a nuisance to other Telecom customers.

Immediately disconnect this equipment should it become physically damaged, and arrange for it's disposal or repair.